


B6、电控换向小排量液压系统原理图（同侧）



工规	DT1	DT2	DT3	DT4	DT5	DT6			DT9	DT10	DT11	DT12	DT13	DT14
正转左旋	+	+		+								+		
正转右旋	+		+		+							+		
反转左旋	+	+			+							+		
反转右旋	+		+	+								+		
高低压差						+								
进油	左旋		+			+						+		
	右旋			+		+						+		
活门	通油	+												+
溢流	保持													+
	恢复													
主缸左旋	+	+				+						+		
主缸右旋	+		+			+						+		
副缸左旋				+								+		
副缸右旋					+							+		
换向									+					
换向反馈									+		+			
风冷													+	
水源										+				
预热	+		+			+						+		