

	3	A4	001614727A1000003	1	电气原理图3	作业控制系统1	
	4	A4	001614727A1000004	1	电气原理图4	作业控制系统2	
	5	A4	001614727A1000005	1	电气原理图5	作业控制系统3	
	6	A4	001614727A1000006	1	电气原理图6	上装控制系统	
	7	A4	001614727A1000007	1	电气原理图7	底盘控制	
	8	A4	001614727A1000008	1	电气系统接线图1		
	9	A4	001614727A1000009	1	电气系统接线图2		
	10	A4	001614727A1000010	1	电气系统接线图3	BJK-6	
	11	A4	001614727A1000011	1	电气系统接线图4	BRC-6	
	12	A4	001614727A1000012	1	电气系统接线图5		
	13	A4	001614727A1000013	1	电气系统接线图6		
	14	表	001614727A1000014	4	元件清单		
	15	表	001614727A1000015	1	电缆表		
	16	表	001614727A1000000	1	图样目录		
	</						













